

IMPORTANT – keep this in mind!



Works at the Coolio™ should only be executed by authorized persons!

Excluded of guarantee:

- by not applying the instructions
- abusive use
- negligence of own maintenance
- by using other cardboard than Freshboard™
- outdoor use



The Freshboard™ has to be placed in an area where the condenser can breathe normally, with a distance of 20 cm between the wall and the Freshboard™.

Indoor use only!

Consult www.coolio-international.com for more detailed warranty conditions.



The filling of the Freshboard™ has to be done in such a way that the openings where the air comes out and is taken back, aren't blocked.

Filling of the Freshboard™ may not pass the „filling line“. See to it that the grid in front of the cooler always stays open!

If the Freshboard™ cardboard display doesn't fit perfectly onto the Coolio™ (gaps or crevices) it will result in a higher temperature.



Clean the condenser at least once a month with a brush or vacuum cleaner. The condenser has to be cleaned at least 4 times a year with a vacuum cleaner.

Clean the in- and outside of the display with tepid water and a non aggressive detergent.



Plug in the Coolio™ only 24 hours after delivery. Put the Coolio™ out of order for 4 hours every month, to clean the aircirculation.



The quality of the Freshboard™ is only guaranteed by single use, and during a max. period of 12 weeks.



The environment conditions shouldn't exceed:

- 22° C temperature
- 60% HR
- 0,2 m/s airspeed



Always transport the Coolio™ vertical. Always put the display vertical.

coolio*

Dumpbin Freshboard 3.0™

Instructions



Distributor

ATTENTION:

Removing the tape of the cardboard box should be done carefully to avoid damage to the display inside.

01



02




03



04



05



06



07




08



09



10



12



11

